

# English Manual



## ►Button Function

Bluetooth/OFF/AUX button: switch ON / switch OFF

- “+ / ►” Short press: next song;  
Long press: volume up;  
(Doesn't work in AUX mode)
- “◀ / -” Short press: previous song;  
Long press: volume down;  
(Doesn't work in AUX mode)
- “▶ / ||” In Bluetooth mode: short press [PLAY / PAUSE] for playing your playlist, or [ANSWER / END] for the management for your phone calls.  
In Bluetooth mode, double click: last number redial; long press for 2 seconds: reject calls

1

## ►Bluetooth Pairing

- Make sure the Bluetooth Speaker is in the off state.
- Press ON/OFF key to Bluetooth mode, blue LED will flash 6 times. And short press Play/Pause key, blue and red LED will flash alternately.
- Follow the operating instruction of your mobile phone for Bluetooth and allow your mobile to searching Bluetooth headset state. Typically, this is done by going to “set up”, “connect” or “Bluetooth” menu and then selecting the option to search Bluetooth devices.
- The mobile can see **Spector** Bluetooth Speaker and ask if you wish to connect your mobile with this speaker. Press “Yes” or “Confirm” to confirm this action.

2


- Enter password or PIN 0000, and press “Yes” or “Confirm”. ( Important notice: If the connection is successful, blue LED will flash. If the pairing is unsuccessful, the LED Blue and Red will still flash alternately. You need to pair again.)

## ►Flashing Instruction

Green LED ON:	In AUX mode
Blue LED flash:	In Bluetooth mode
Red and blue LED flash alternately:	Bluetooth pairing
Red LED ON:	Charging
Red LED OFF:	Full power
Red LED Flash:	Low power


3

## Multifunction Button



4

## ►Jack Instruction



5

## ►Specifications

### ■AUX Input plug

Push the Bluetooth/OFF/AUX button on AUX mode.  
Plug the auxiliary plug into any device with 3.5mm jack plug: notebook, smartphone, MP3/MP4 players.

### ⑧Bluetooth Handfree

Push the Bluetooth/OFF/AUX button on Bluetooth mode.  
Bluetooth management of your playlist and phone calls.

### ①Stereo Bluetooth

Stereo Bluetooth Speakers, supporting A2DP/AVRCP, let you enjoy wireless HI-FI stereo music.

6

## ►Technical characteristics

Bluetooth version: V2.1	Auxiliary input jack: 3.5mm
Battery voltage: 3.7V	Rechargeable battery: 520mAh (via USB cable)
Charge voltage: 5V	Loudspeaker size: 45mm 4Ω 3W
Distortion: <0.5%	S/N: >95Db
Net weight: 230g	Size: 60*60*50mm

## ►Contents

- 1 stereo bluetooth speaker
- 1 USB and 3.5mm jack cable

7

## ►Safety regulations

- Read the user guide carefully.
- Keep it away from children.
- Do not hit or beat the product. Do not throw the product into fire.
- Do not expose to high temperatures or damp. Product performance will decrease when it is used in cold regions.
- Do not block speaker's net above the body.
- Please send to repair when the product is broken. Do not disassemble it by yourself.
- It's not covered under warranty when the product has metal of rust, surface spalling and other natural oxidation.

8

## ►Warranty Card

When Purchasing this product, please fill in this card and be properly preserved.

Product Name: \_\_\_\_\_

Purchase Date: \_\_\_\_\_

Customer Name: \_\_\_\_\_

Customer Tel: \_\_\_\_\_

Customer Add: \_\_\_\_\_

Distribution: \_\_\_\_\_

Distributor Tel: \_\_\_\_\_

Distributor Add: \_\_\_\_\_

Signature: \_\_\_\_\_

9